


PRESENTATION PLATTER

PRODUCT MANUAL



Cleaning:

To protect the tray against dirt it is treated with a food grade oil. If the tray starts to look dull, repeat the treatment. Rub the oil in the wood with a clean cloth, let it soak for one hour. Wipe it of with a dry cloth. The glass part is suitable for the dishwasher. The wooden part is not.

made in The Netherlands



www.ontwerpduo.nl